



## SECTION 08872

### ARCHITECTURAL WINDOW FILM

#### PART 1 GENERAL

##### 1.1 SECTION INCLUDES

- A. Interior Window Film.
- B. Decorative Window Film.
- C. Privacy Window Film.

##### 1.2 RELATED SECTIONS

- A. Section 08500 - Windows: Windows to receive architectural window film.
- B. Section 08600 - Skylights: Glass Skylights to receive architectural window film.
- C. Section 08800 - Glazing: General Glazing applications to receive architectural window film.
- D. Section 08900 - Glazed Curtain Walls: Curtain Walls to receive architectural window film.

##### 1.3 REFERENCES

- A. ASHRAE - American Society for Heating, Refrigeration, and Air Conditioning Engineers; Handbook of Fundamentals, 1997 Edition.
- B. ASTM E 84 - Standard Method of Test for Surface Burning Characteristics of Building Materials.
- C. ASTM E 308 - Standard Recommended Practice for Spectrophotometry and Description of Color in CIE 1931 System.
- D. ASTM E 903 - Standard Methods of Test for Solar Absorbance, Reflectance and Transmittance of Materials Using Integrating Spheres.
- E. ASTM G 26 - Standard Practice for Performing Accelerated Outdoor Weatherizing for Non-metallic Materials Using Concentrated Natural Sunlight.

##### 1.4 PERFORMANCE REQUIREMENTS

- A. Fire Performance: Surface burning characteristics when tested in accordance ASTM E 84:

1. Flame Spread: 25, maximum.
2. Smoke Developed: 450, maximum.

#### 1.5 SUBMITTALS

- A. Submit under provisions of Section 01300.
- B. Product Data: Manufacturer's data sheets on each product to be used, including:
  1. Preparation instructions and recommendations.
  2. Storage and handling requirements and recommendations.
  3. Installation methods.
- C. Selection Samples: For each finish product specified, two complete sets of color chips representing manufacturer's full range of available colors and patterns.
- D. Verification Samples: For each finish product specified, two samples representing actual product, color, and patterns.

#### 1.6 QUALITY ASSURANCE

- A. Manufacturer Qualifications: All primary products specified in this section will be supplied by a single manufacturer with a minimum of ten (10) years experience.
- B. Installer Qualifications: All products listed in this section are to be installed by a single installer with a minimum of five (5) years demonstrated experience in installing products of the same type and scope as specified.
  1. Provide documentation that the installer is authorized by the Manufacturer to perform Work specified in this section.
  2. Provide a commercial building reference list of 5 properties where the installer has applied window film. This list will include the following information:
    - a. Name of building.
    - b. The name and telephone number of a management contact.
    - c. Type of glass.
    - d. Type of film.
    - e. Amount of film installed.
    - f. Date of completion.
  3. Provide a Glass Stress Analysis of the existing glass and proposed glass/film combination as recommended by the film manufacturer.
- C. Mock-Up: Provide a mock-up for evaluation of surface preparation techniques and application workmanship.
  1. Finish areas designated by Architect.
  2. Do not proceed with remaining work until workmanship, color, and sheen are approved by Architect.
  3. Refinish mock-up area as required to produce acceptable work.

#### 1.7 DELIVERY, STORAGE, AND HANDLING

- A. Store products in manufacturer's unopened packaging until ready for installation.
- B. Store and dispose of hazardous materials, and materials contaminated by hazardous materials, in accordance with requirements of local authorities having jurisdiction.

#### 1.8 PROJECT CONDITIONS

- A. Maintain environmental conditions (temperature, humidity, and ventilation) within

limits recommended by manufacturer for optimum results. Do not install products under environmental conditions outside manufacturer's absolute limits.

## 1.9 WARRANTY

- A. At project closeout, provide to Owner or Owners Representative an executed current copy of the manufacturer's standard limited warranty against manufacturing defect, outlining its terms, conditions, and exclusions from coverage.

## PART 2 PRODUCTS

### 2.1 MANUFACTURERS

- A. Acceptable Manufacturer: 3M Window Film , which is located at: 3M Center Bldg. 0223-02-S-24 ; St. Paul, MN 55144-1000; Toll Free Tel: 888-364-3577; Tel: 651-737-1053 ; Fax: 651-736-0611; Email: [windowfilm@mmm.com](mailto:windowfilm@mmm.com); Web: [www.3m.com/windowfilm](http://www.3m.com/windowfilm)
- B. Substitutions: Not permitted.
- C. Requests for substitutions will be considered in accordance with provisions of Section 01600.
- D. Fasara - Oslo Decorative / Privacy Glazing Film:
  - 1. Ultraviolet Rejected (ASTM E 903): Not less than 99 percent.
  - 2. Visible Light Transmission (ASTM E 903, ASTM E308): Not more than 77 percent.
  - 3. Visible Light Rejected (ASTM E 903): Not less than 9 percent.
  - 4. Solar Heat Reduction: Not less than 8 percent.
  - 5. Shading Coefficient at 90 Degrees (Normal Incidence) (ASTM E 903): Not less than 0.89.
  - 6. 3M Window Film Point of Contact - Michael Hassenauer 651-737-1053. Email: [mjhassenauer@mmm.com](mailto:mjhassenauer@mmm.com).

## PART 3 EXECUTION

### 3.1 EXAMINATION

- A. Do not begin installation until substrates have been properly prepared.
- B. If substrate preparation is the responsibility of another installer, notify Architect of unsatisfactory preparation before proceeding.

### 3.2 PREPARATION

- A. Clean surfaces thoroughly prior to installation.
- B. Prepare surfaces using the methods recommended by the manufacturer for achieving the best result for the substrate under the project conditions.

### 3.3 INSTALLATION

- A. Install in accordance with manufacturer's instructions.
- B. Cut film edges neatly and square at a uniform distance of 1/8 inch (3 mm) to 1/16 inch (1.5 mm) of window sealant. Use new blade tips after 3 to 4 cuts.

- C. Spray the slip solution, composed of one capful of baby shampoo or dishwashing liquid to 1 gallon of water, on window glass and adhesive to facilitate proper positioning of film.
- D. Apply film to glass and lightly spray film with slip solution.
- E. Squeegee from top to bottom of window. Spray slip solution to film and squeegee a second time.
- F. Bump film edge with lint-free towel wrapped around edge of a 5-way tool.
- G. Upon completion of film application, allow 30 days for moisture from film installation to dry thoroughly, and to allow film to dry flat with no moisture dimples when viewed under normal viewing conditions.

#### 3.4 CLEANING AND PROTECTION

- A. Remove left over material and debris from Work area. Use necessary means to protect film before, during, and after installation.
- B. Touch-up, repair or replace damaged products before Substantial Completion.
- C. After application of film, wash film using common window cleaning solutions, including ammonia solutions, 30 days after application. Do not use abrasive type cleaning agents and bristle brushes to avoid scratching film. Use synthetic sponges or soft cloths.

END OF SECTION